

HYDRATE PHOENIX: DESIGNING A WATER HARVESTING LANDSCAPE



PRESENTED BY:











Water Harvesting Landscape Design Harvest the rain with only a shovel




Outline

- 1. What: Water Harvesting Principles
- 2. Where: Getting Started at Your Site
- 3. How: Water Harvesting Essentials

Water Harvesting Principles

<u>Rainwater</u> <u>Harvesting for</u> <u>Drylands and</u> <u>Beyond</u>

by Brad Lancaster





1. Begin with Long and Thoughtful Observation Water Harvesting Principles



2. Start at the Top Water Harvesting Principles



3. Start small and simple Water Harvesting Principles




4. Spread and infiltrate the flow of water Water Harvesting Principles



5. Always plan for an overflow route and manage overflow as a resource

Water Harvesting Principles



6. Maximize living and organic groundcover Water Harvesting Principles




7. Maximize beneficial relationships and efficiency – STACKING FUNCTIONS

Water Harvesting Principles



8. Continually reassess your system Water Harvesting Principles

How does water harvesting link to watershed health?




Hydro-local

Valuing and stewarding local, renewable water resources instead of depleting distant watersheds and rivers

WHERE?



1. Begin with Long and Thoughtful Observation Water Harvesting Principles



DRAW YOUR SITE

- Property lines
- \circ House
- Other permanent structures (storage sheds, pool, driveway, sidewalks, etc.)
- Existing trees and shrubs
- Mark direction North, South, East, West


Sectors/ Factors

Sectors deal with the wild energies...from outside our system and pass through it.

Intro to Permaculture pg. 14

- Sun
- Water
- Wind
- Fire
- Wildlife
- Pollution
- \circ View
- Utilities
- Community

UTILITIES



White = Proposed Excavation

Pink = Temporary Survey Markings

Red = Electric Power Lines, Cables, Conduit and Lighting Cables


Yellow = Gas, Oil, Steam, Petroleum or Gaseous Materials

Orange = Communication, Alarm or Signal Lines, Cables or Conduit

Elue = Potable Water

Purple = Reclaimed Water, Irrigation and Slurry Lines

Green = Sewer and Drain Lines




UTILITIES

- Water
- Gas
- Sewer
- Electric
- Cable
- Telephone
- Irrigation







NOAA Solar Calculator http://www.esrl.noaa.gov/gmd/grad/solcalc/

SEASONAL SHADE PATTERNS

1:00 PM




9:00 AM

5:00 PM



Winter Solstice 2008




Plan with the SUN

- Summer
- Winter
- Equinox
- Hot spots
- Shadow patterns
- Microclimates

Watersheds


Watershed: a watershed is the land area that drains water to a particular stream, river or lake. An area that drains to a common point.





Water





Plan with Water


- Watersheds, subwatersheds
- o Water movement
- Slope, topography
- o Hose Bibs
- o Annual rain fall
- Determine square feet
- Multiply square feet by .623
 to convert into gallons for a 1" rain

SECTORS / FACTORS

Sectors deal with the wild energies...from outside our system and pass through it.

Intro to Permaculture pg. 14

- ∘ Sun
- Water
- Wind
- Fire
- Wildlife
- Pollution
- View
- Utilities
- Community





Questions?

HOW?

Water Harvesting (Passive) **Earthworks**

Created features formed from soil, rock, or plant material


Use gravity to distribute rain runoff

- SLOW
- SPREAD
- SINK

Cheapest storage option for large amounts of rainwater



Earthworks Slow it, Spread it, Sink it!



Convey: Swales








Infiltration: Basins










Organic mulch is applied to basins, 2 – 4 inches thick, to help infiltrate more water, reduce evaporation of soil moisture, and replenish nutrients in the soil.

Slopes and Soil Retention:











Raised: Berms













Sizing Earthwork Capacity

- 1. Stormwater retention
 - (Design storm event: 25yr, 50yr, 100yr) Flood control (Lancaster, Vol 2, pg 136)
 - Calculate open capacity of feature
 - Size to meet estimated stormwater runoff
 - Ensure water will percolate in 12 to 24hrs
- 2. Percolation Rate Method
 - Greywater Systems (Ludwig, A., pg 13)
 - Surface area needed to infiltrate peak water volume
 - Based on percolation rate and discharge volume

3. Plant Needs

Irrigation/Dryland farming (Lancaster, Vol 2, pg 80)

Sized to capture sufficient runoff from catchment area to irrigate specific plant(s)

Sizing for Stormwater Retention



Sizing Earthwork Capacity

Runoff Coefficients for the Southwest United States

Surface	Runoff Range	Notes
Roof	0.80-0.95	Metal: 0.95, Concrete/asphalt: 0.90, Built up tar/gravel: 0.85 - 0.80
Paving	0.9095	Older irregular surfaces may be lower than 0.90.
Bare Soil	0.20 - 0.75	A best guess based on characteristics of soil and experience. Unprotected soil surfaces tend to surface seal easily unless high levels of organic material or a high content of sand is present.
Soil with Vegetation	0.10 - 0.60	Leaf litter, basal area, and roots all help increase infiltration rates and can also absorb water.
Grass/Lawn	0.05 - 0.35	A high density of leaf area and root densities help reduce runoff. If soil underneath is compacted runoff rates can be higher.
Gravel	0.20-0.75	Use the coefficient of the ground below the gravel

*Chart adapted from 1) Lancaster, Brad. 2006. Rainwater Harvesting for Drylands, Vol.1.Rainsource Press and 2) Waterfall, Patricia. 2006. Harvesting Rainwater for Landscape Use 2nd Ed. Plma County Cooperative Extension.

Potential Harvested Rainwater Volume (gallons)

Catchment area (ft²) x rainfall depth (in) x 0.623 (conversion) x Runoff Coef. = Volume (gallons)

Calculating Basin Volume (gallons)

- Quick Estimate: Average Surface Area (ft³) x Average depth (ft) x 7.48 (gal/ft³) = Volume (gallons)
- More Accurate Ballpark: Depth (ft) x ([L1 x W1] + [L2 x W2]) / 2 x 7.48 (gal/ft⁺) = Volume (gallons)
- Most Accurate: CAD or GIS based delineation and calculation

Locating Earthworks

Consider:

- Utility Lines: ~ 2-10ft distance (Call a Utility Locating Service!)
- Structural Foundations: ~10ft distance
- Pathways: raise and use to manage runoff (i.e. berm)
- Right-of-ways (ROW): lookup local restrictions

Remember the 3 Elevations:





Fig. 1.12. Three important elevations: Elevation 1: Overflow spillway is the low point of earthwork's perimeter. Elevation 2: Spillway is low enough to ensure nothing is accidentally flooded. Elevation 3: Basin is lower than elevation of spillway to ensure water is harvested, rather than drained.

50 RAINWATER HARVESTING FOR DRYLANDS AND BEYOND - VOLUME 2

Water Level (Bunyip)



Toolbox – Passive Features



Vegetation: Native / Adapted



CAUTION!!

Flooding

Slowing Runoff -> backing up surface flow upstream

Ponding -> standing water risks

Mosquitos -> minimize ponding time

Structural and Utilities -> protect infrastructure

Soil Saturation/Loading -> slope instability/failure

Walkability/Bikeability-> Always promote alternative transportation activities

General Safety -> vertical drops (<18"); excavation and sediment control; traffic visibility; plant types, etc...

Maintenance

Observe:

- During and after rainfall events
- Seasonally

Check:

- Overflow Appropriately sized and placed
- Percolation Duration of standing water
- Capacity Loss, undersized, ...
- Stability Rocks are secured; soil surface stable
- Plant Productivity Sufficient water, placement, ...
- Mulch Material Need to add more?

Adjust & Improve:

- Design capacity, aesthetics, water routing, ...
- Plants species, placement, ...
- Soil Improvements drainage, nutrients, ...

Questions?

Thank You



